

VB-3000 SERIES BRASS VALVE

DESCRIPTION

VB-3000 series brass valve is equipped with electrical control device, it can be used to control the flow of vapor or cool / heat water in central air-conditioning, heating, water handling and industrial processing industry system.



MATERIAL DESCRIPTION AND TECHNICAL DATA

PRODUCT		VB-3000 Standard Valve	VB-3000V High temperature valve (Vapor Valve)		
	VALVE BODY	Casting brass	High intensity casting brass		
	VALVE STEM	1Cr18Ni9	1Cr18Ni9		
MATERIAL	SEALING MATERIAL	Fluon filler and O-ring Nitrile rubber sealing combination	Fluon filler and O-ring Fluorine rubber sealing combination		
	VALVE PLATE	Forging brass with Nitrile rubber gasket	High intensity forging brass with Fluon gasket		
PRESSURE RATING		1.6MPa (At 95℃)	1.6MPa (At 180℃)		
PIPE CONNECTION		G / BSP			
WO	RKING MEDIUM	Water	Water / Vapor		
FLUID TEMPERATURE		2~94 ℃	2~180℃		
FLOWING CHARACTERISTICS		Equal percentage			
LEAKAGE		Less than 0.05% of Kv factor			
CLOS	SING DIRECTION	Valve stem goes up is closing			

SPECIFICATIONS AND TECHNICAL DATA

STANDARD VALVE	VAPOR VALVE	TYPE	SIZE (DN)		кv	STANDARD VALVE MAX. DIFF. PRES. (MPa)		VAPOR VALVE MAX. DIFF. PRES. (MPa)		STROKE
MODEL	MODEL		mm	in		FIT WITH VA-31XX	FIT WITH VA-32XX	FIT WITH VA-31XX	FIT WITH VA-32XX	(mm)
VB-3200-25	VB-3200-25V		25	1"	8	1.0	1.4	0.8	1.2	15
VB-3200-32	VB-3200-32V		32	1¼"	16	0.75	1.1	0.6	1.0	19
VB-3200-40	VB-3200-40V	2-Way	40	11⁄2"	25	0.5	0.8	0.4	0.7	19
VB-3200-50	VB-3200-50V		50	2"	40	0.3	0.5	0.2	0.4	22
VB-3200-65	VB-3200-65V		65	21⁄2"	63	0.2	0.35	0.2	0.35	22
VB-3300-25	VB-3300-25V	3-Way	25	1"	8	1.0	1.4	0.8	1.2	15
VB-3300-32	VB-3300-32V		32	1¼"	16	0.75	1.1	0.6	1.0	19
VB-3300-40	VB-3300-40V		40	1½"	25	0.5	0.8	0.4	0.7	19





VB-3300-50	VB-3300-50V	50	2"	40	0.3	0.5	0.2	0.4	22
VB-3300-65	VB-3300-65V	65	2½"	63	0.2	0.35	0.2	0.35	22

DIMENSIONS

FIGURE	MODEL	DIMENSIONS (mm)					
TIGORE	NODEL	А	В	С			
μ	VB-3200-25(V)	110	63	108			
	VB-3200-32(V)	120	69	108			
	VB-3200-40(V)	130	71	111			
	VB-3200-50(V)	145	77	114			
	VB-3200-65(V)	175	83	121			
	VB-3300-25(V)	110	81	108			
В	VB-3300-32(V)	120	85	108			
	VB-3300-40(V)	130	85	111			
	VB-3300-50(V)	145	96	114			
	VB-3300-65(V)	175	104	121			

INSTALLATION


- 1. Before mounting the valve, make sure that the pipe is clean and free from soldering scraps, metal sheet, sand, stone or other sundries.
- 2. The pipe and valve body must be connected perfectly without vibration. The water flow direction should be the same as marked on the valve body.
- 3. If the valve is mounted in the factory, which is working with high temperature fluid (steam, overheated water, diathermic liquid), it is necessary to use expansion joint to avoid expanding the pipe and pressing the valve.
- 4. The actuator should be mounted vertically on the valve body, and avoid the actuator below the valve body. Remain enough space so that the actuator can be taken down from the valve body during the daily maintenance.
- 5. Power supply must be shut off or insulated when maintain the valve. There should not have pressure in the water system.
- 6. For other installation requirements, please refer to the Installation Instruction of the actuator.






FLOW DIRECTION DIAGRAM

TWO-WAY VALVE



THREE-WAY VALVE



Diverting 3-way

Mixing 3-way

